

General Product information



This product is suitable for indoor dry locations only.

This product is to be installed to a standard 4" junction box with a 3" round plaster ring or an octagon junction box.




CAUTION - RISK OF FIRE



This product requires installation by a qualified electrician. Before installing be sure to read all instructions and TURN POWER OFF TO THE JUNCTION BOX

Adjusting the Fixture Height

- Measure the desired height (H) you want the fixture to hang below the ceiling.
- 2 Thread the power cord through the shade assembly, thumb nut, canopy, crossbar assembly and cord grip.
- 3 Tighten cord grip at the desired length H, then tie a knot in cord above grip.



Making Electrical Connections

Make electrical connections as shown using the supplied wire nuts.

Mounting the Fixture

5 Attach the crossbar to the junction box using the supplied #8 screws.



