General Product Information



This product is suitable for indoor dry and damp locations only.

## CAUTION - RISK OF FIRE This product requires installation by a qualified electrician. Before installing be sure to read all instructions and TURN POWER OFF TO THE JUNCTION BOX



Adjusting the Fixture Height

1)Determine the desired height (H) that you want the fixture to hang below the ceiling.

CRITICAL NOTE: Cut the Upper Stem using an appropriate cutting method for steel tube.

2)If needed, cut the one of the stems to the desired drop length so that the combined length of the provided stems is equal to the desired height (H). After cutting, drill a hole in the top of the stem using the included 5/32 drill bit.



3) Thread the LED module power cables through the shade frame. Screw the threaded rod on LED module into threaded fitting in frame.



Figure 3



4) Grab the three segments that make up the rigid stem. Each stem will have a 1/8IPS nipple on one end.

5)Feed the power cable from the fixture through a lock nut and one of the stems, starting at the end with the 1/8IPS nipple. Thread the 1/8IPS nipple into the threaded adapter on top of the fixture and fasten the lock nut with a wrench to secure the stem to the fixture. Feed the power cable through the second stem, starting at the end with the 1/8IPS nipple and connect the stems.



6) Install the canopy mounting plate to the junction box using the included 8-32 screws.

7) With the canopy cover on the rigid stem, feed the stem through the center hole of the canopy. Align the clearance hole in the stem with the tip of the set screw on the half ball to secure the fixture.



Cerr

8) Make the electrical connections as shown below using the provided wire nuts.

OPTIONAL: For 0-10V dimming control, connect the purple and gray wires to a 0-10V dimming signal.



Cerr

9) Install the canopy cover over the mounting plate assembly. The canopy cover will attach to the mounting plate magnetically.



