

General Product Information

This product is suitable for indoor dry and damp locations only.


Junction Box Requirements: This fixture can be mounted to most standard junction boxes. It is the installer's responsibility to ensure that the site conditions, junction box, and fasteners used are suitable to support the weight of the fixture.

Fixture can be dimmed with TRIAC, ELV, or 0-10V dimming at 120 VAC input. For 240 or 277 VAC input, fixture is only dimmable with 0-10V dimming.




Damage due to incorrect connections can be detected at the factory and is not covered under warranty.


CAUTION - RISK OF FIRE

This product requires installation by a qualified electrician. Before installing be sure to read all instructions and **TURN POWER OFF TO THE JUNCTION BOX**



- ① Measure the desired height (H) that you want the fixture to hang below the ceiling.
- ② Install the leather standoff bar by screwing it into the shade coupler. Pulling the power cord taught will help to screw the bar in and not twist the power cord.
- ③ Pull the upper accent rod up until the leather is taut and tighten the set screw.
- ④ Align the screw heads on the wood hub with the holes on the light engine. Secure the hub to the fixture with the brass thumb nuts.





- ⑤ Cut and strip the power cord about an inch longer than the desired height (H).
- ⑥ Remove the driver plate from the mounting plate by loosening the short 8-32 screws (keep these screws, they will be needed later).
- ⑦ Thread the cord through the canopy strain relief, canopy, and driver plate assembly in that order.
- ⑧ Install the mounting plate to junction box using the supplied long 8-32 screws.
- ⑨ Pull the steel aircraft cables through the cable grippers to the desired drop height (H).
- ⑩ Make electrical connections as shown in the wiring diagram below using wire nuts.

CRITICAL NOTE: If 0-10V dimming control is to be used, connect the 0-10V driver output leads to the 0-10V dimmer. Otherwise, the tinned ends of these leads should be snipped off and the leads should be capped individually such that they remain isolated from one another.

- ⑪ Slip the driver plate up and reinstall to the mounting plate using the short 8-32 screws removed in step ⑥.
- ⑫ Slip the canopy up to cover the mounting plate and driver plate assembly and secure the canopy with the canopy strain relief.
- ⑬ Pull the power cord taught enough so there is no slack in the cord, but the steel aircraft cables are still holding up the fixture. Tighten the set screw in the canopy strain relief to hold the cord in place.

